



FIG. 16 FRAME GROUP




F16-1	13-0101-00	C.B.C. CROSS BAR	工字形管	1	
F16-2	13-0801-00	CANOPY TOP	雨篷	1	
F16-3	8.070.064	C.B.C. BAR CAGE(B.R.S)	上梁管	2	
F16-4	8.070.066	FRAME COMP.(B.R.S.)	车架总成	1	
F16-5	13-0201-00	FR. HOOD, UPPER	前舱盖下	1	
F16-6	7.010.017	TUBE SEAT Φ25	管接头	8	
F16-7	9.908.055N	SOCKET BOLT M8X1.25X55	法兰螺栓	8	
F16-8	8.010.047	R-WASHER	R形垫圈	16	
F16-9	9.908.050N	SOCKET BOLT M8X1.25X50	法兰螺栓	4	
F16-10	9.220.008	LOCKING FLANGE NUT M8	锁紧螺母	4	
F16-11	6.000.144	FRONT REFLECTOR	侧光反射片(带2只螺母)	2	
F16-12	13-0202-03	FR. HOOD, LOWER	前舱盖下	1	
F16-13	6.000.083	FOAM PADDING	护套管	2	
F16-14	003-050016-00	SCREW BOLT, M5X16	螺钉	12	
F16-15	7.020.012	RUBBER FOOT PLATE	橡胶垫脚	2	
F16-16	13-0206-00	HEADLIGHT UNIT	大灯总成	2	
F16-17	9.108.050	FLANGE BOLT M8 X 1.25 X 50	法兰螺栓	2	
F16-18	9.220.008	NUT M8	螺母	2	
F16-19	9.000.004	POSITION LIGHT BULB 3W 12V	灯泡	2	
F16-20	9.700.004	BANJO BOLT M10X24	螺栓	6	
F16-21	6.000.089	BRAKE HOSE ASSY. L. 34"	制动软管左34"	1	
F16-22	6.000.090	BRAKE HOSE ASSY. R. 43"	制动软管右43"	1	
F16-23	6.000.091	BRAKE HOSE ASSY. RR. 75"	制动软管后75"	1	
F16-24	6.000.034B	THROTTLE CABLE COMP.	油门线总成	1	
F16-25	6.000.040	REVERSE CABLE COMP.	倒档线总成	1	
F16-26	6.000.050	PARKING BRAKE CABLE COMP.	手刹线总成	1	
F16-27	003-060012-00	PAN SCREW, M6X12	大平头螺栓	4	
F16-28	7.020.049	HEADLIGHT RUBBER MOUNT	大灯橡胶垫	4	
F16-29	9.090.003	HEADLIGHT BULB 35W/35W/ 12V	大灯灯泡	2	
F16-30	13-0203-03R	GRILL ORNAMENT, RH.	右网眼罩	1	
F16-31	13-0203-03L	GRILL ORNAMENT, LH.	左网眼罩	1	
F16-32	13-0501-00	GRIP, HANDLEBAR	乘客手柄套	1	
F16-33	6.000.102	FRONT FENDER BRACKET,R.	前泥板支架左	1	
F16-34	9.106.014	FLANGE BOLT M6X14	前泥板法兰螺栓	6	
F16-35	7.010.034	FENDER, FR.	前泥板	2	
F16-36	6.000.067	FRONT FENDER BRACKET, L.	前泥板支架右	1	
F16-37	9.100.640	BOLT M6 X 40	螺栓	2	
F16-38	9.210.008	LOCKING FLANGE NUT M8	锁紧法兰螺母	10	

FIG. 17 STEERING SHAFT ASSY.




F17-1	7.010.041	STEERING BOLT COVER	方向盘盖(两脚有花)	1	
F17-2	9.100.612	BOLT STRAP M6X12	螺栓 GB5787	3	
F17-3	8.030.024	SPINDLE BRACKET	制动泵安装座	1	
F17-4	7.020.038	STEERING WHEEL	方向盘	1	
F17-5	6.000.122	STEERING SHAFT	方向柱	1	
F17-6	9.030.012	BEARING NK20/16	尼龙衬圈 7.010.026	2	
F17-7	9.700.020	SPECIAL WASHER Φ20	特种垫圈	1	
F17-8	9.700.120	CIRCLIP Φ20	弹簧挡圈	1	
F17-9	9.100.825	BOLT M8X25	螺栓子 GB5787	2	
F17-10	9.400.008	LOCKING WASHER Φ8	锁紧垫圈	2	
F17-11	6.000.093-250	STEERING KNUCKLE	万向节	1	
F17-12	4.000.035-250	STEERING GEAR	转向齿轮	1	
F17-13	9.108.025	FLANGE BOLT M8X1.25X25	法兰螺栓 GB5787	4	
F17-14	9.900.016	ROUND NUT M16X1.5	圆螺母	2	
F17-15	4.000.008-250	STEERING BALL JOINT	球头	2	
F17-16	9.200.010	NUT M10	螺母	2	
F17-17	7.020.002-250	BALL JOINT DUST COVER.	方向机防尘罩	2	
F17-18	8.010.157-250	TIE ROD	横拉杆	2	
F17-19	6.000.062-250	ROD END	横拉杆球头	2	
F17-20	9.300.010	FLAT WASHER Φ10	平垫圈	2	
F17-21	9.400.010	LOCKING WASHER Φ10	锁紧垫圈	2	
F17-22	9.800.010	CASTLE NUT M10	六角螺母	2	
F17-23	9.500.215	COTTER PIN Φ2X15	开口销	2	
F17-24	4.000.051	TILT STEERING HOUSING	方向盘连接杆	1	
F17-25	8.020.014	STEERING GEAR BRACKET	转向齿轮支架	2	
F17-26	9.220.008	LOCKING FLANGE NUT. M8	锁紧法兰螺母 GB6170	8	
F17-27	9.708.145	THROTTLE PEDAL BOLT M8X1.25X14	油门踏板螺栓	1	
F17-28	8.040.001	THROTTLE PEDAL RETURN SPRING, L	油门踏板复位弹簧	1	
F17-29	9.108.040	FLANGE BOLT M8X1.25X40	法兰螺栓	2	
F17-30	9.200.008	NUT M8	螺母	2	
F17-31	4.000.016	THROTTLE PEDAL COMP.	油门踏板总成	1	
F17-32	9.600.515	PAN SCREW M5X15	大平头螺栓	2	
F17-33	9.300.005	FLAT WASHER Φ5	平垫圈	2	
F17-34	9.210.005	NYLON LOCK NUT M5	尼龙锁紧螺母 GB6170	2	
F17-35	4.000.015	BRAKE PEDAL COMP	制动踏板总成	1	
F17-36	9.700.624	PIN 6X24	销子	1	
F17-37	8.010.081	SPINDLE PIN	制动泵顶杆	2	
F17-38	9.500.212	COTTER PIN 2X12	开口销	1	
F17-39	6.000.063	BRAKE LAMP SWITCH ASSY.	液压开关	1	
F17-40	9.600.306	PAN SCREW M3X6	圆螺母	2	
F17-41	7.010.004	PEDAL BUSH	踏板衬圈	4	
F17-42	8.040.007	BRAKE PEDAL RETURN SPRING, R	制动踏板复位弹簧右	1	
F17-43	9.708.222	BRAKE PEDAL BOLT M8X1.25X222	制动踏板螺栓	1	
F17-44	6.000.076	MASTER CYLINDER	制动泵主泵	1	
F17-45	9.108.035	BOLT-WASHER M8X1.25X35	螺栓	2	
F17-46	7.020.036	THROTTLE PEDAL PAD	油门踏板套	1	
F17-47	7.020.037	BRAKE PEDAL PAD	制动踏板套	1	
F17-48	8.070.044	MASTER CYLINDER BRACKET	踏板支架	2	
F17-49	8.010.220	ADJUSTING NOB	调节器	1	
F17-50	8.010.221	ADJUSTING NOB BLOCK	调节器块	1	
F17-51	9.108.110	TILT STEERING BOLT, M8X1.25X110	转向器螺栓	1	
F17-52	7.010.003	TILT STEERING LOCKING BUSH	转向器锁紧衬圈	2	
F17-53	8.010.222	COLLAR	衬管	1	

FIG. 18 SUSPENSION ARM ASSY.




F18-1	2.000.028	STRUT AND SPINDLE SUPPORT, R	右转向柱	1	
F18-2	9.108.105	FLANGE BOLT M8X1.25X105	法兰螺栓	2	
F18-3	8.010.015	UPPER SUSPENSION ARM COLLAR	上摇架衬管	2	
F18-4	7.010.003	UPPER SUSPENSION ARM BUSHING	上摇架衬圈	4	
F18-5	4.000.004	UPPER SUSPENSION ARM	上摇架	2	
F18-6	9.220.008	LOCKING FLANGE NUT. M8	锁紧法兰螺母	2	
F18-7	7.010.140	LOCKING FLANGE NUT. M12	锁紧法兰螺母	4	
F18-8	7.020.025	SHORT BALL JOINT COVER	球头防尘罩	4	
F18-9	8.020.053	BALL HEAD SPACER	球头隔圈	4	
F18-10	2.000.027	STRUT AND SPINDLE SUPPORT, L	左转向柱	1	
F18-11	9.908.014	BOLT STRAP M8X14	螺栓	4	
F18-12	8.010.014	LOWER SUSPENSION ARM COLLAR	下摇架衬管	4	
F18-13	9.906.012	BOLT STRAP M6X12	螺栓	12	
F18-14	13-0901-03R	FRONT TIRE & WHEEL, RIGHT 19X7-8	前轮总成右	1	
F18-15	7.020.016	PAD SET. FR. BRAKE CALIPER	刹车片	2	
F18-16	6.000.028	FRONT BRAKE CALIPER. L	前制动泵左	1	
F18-17	8.010.054	FRONT DISC BRAKE	前刹车盘	2	
F18-18	9.040.002	DUST SEAL 47X25-7	油封	2	
F18-19	9.030.002	BEARING 6204-Z	轴承	2	
F18-20	9.710.031	TIRE BOLT M10X1.25X31	轮胎螺栓	8	
F18-21	8.010.085B	FRONT WHEEL HUB	前轮毂	2	
F18-22	9.030.010	BEARING 6202-Z	轴承	2	
F18-23	9.220.010	LOCKING FLANGE NUT M10	锁紧法兰螺母	8	
F18-24	001-190708-00	FRONT TIRE, LEFT 19X7-8	前轮胎左(无轮钢)	1	
	001-190708-00	FRONT TIRE, RIGHT 19X7-8	前轮胎右(无轮钢)	1	
F18-25	002-100080-03	FRONT WHEEL 8" STEEL BLACK	前轮钢(8寸黑色)	2	
F18-26	9.220.010	LOCKING FLANGE NUT M10	锁紧法兰螺母	16	
F18-27	9.800.012	CASTLE NUT M12	六角螺母	2	
F18-28	9.500.220	COTTER PIN Φ2X20	开口销	2	
F18-29	7.020.039	FR. HUB COVER.	前轮毂护罩	2	
F18-30	9.110.040	FLANGE BOLT M10X1.25X40	法兰螺栓	4	
F18-31	6.000.095	FRONT BRAKE CALIPER. R	前制动泵右	1	
F18-32	6.000.325	CUSHION ASSY. FR L=325	前减震	2	
F18-33	9.110.080	FLANGE BOLT M10X1.25X80	法兰螺栓	4	
F18-34	8.020.034	LOWER SUSPENSION ARM DUST CAP	下摇架防尘罩	8	
F18-35	7.010.002	LOWER SUSPENSION ARM BUSHING	下摇架衬圈	8	
F18-36	9.040.001	O-RING Φ 21.2X2.65	O形圈	8	
F18-37	4.000.023	LOWER SUSPENSION ARM ASSY.	下摇架总成	2	
F18-38	13-0901-03L	FRONT TIRE & WHEEL, LEFT 19X7	前轮总成左	1	
F18-39	8.010.140	ACORN NUT M12	盖形螺母	2	

FIG. 19 REAR CARGO RACK/SEAT/BELT




F19-1	2.000.061	REAR CARGO RACK (B.G.R.)	后行李架	1
F19-2	7.010.017	TUBE SEAT Φ25	Φ 25半圆垫	2
F19-3	8.080.051	RACK SUPPORT ARM (B.G.R.)	书包架撑杆	1
F19-4	9.108.020	FLANGE BOLT M8X1.25X20	法兰螺栓 GB5787	4
F19-5	9.220.008	LOCKING FLANGE NUT, M8	锁紧法兰螺母 GB6187	4
F19-6	6.000.053	FUEL TANK CAP COMP.	油箱盖总成	1
F19-7	4.000.011	FUEL TANK COMP.	油箱总成	1
F19-8	9.108.025	FLANGE BOLT M8X1.25X25	法兰螺栓	4
F19-9	8.010.034	TANK COLLAR.	油箱衬管	4
F19-10	7.020.005	RUBBER MOUNT	油箱衬垫	4
F19-11	9.300.008	FLAT WASHER Φ8	平垫圈	4
F19-12	9.210.008	NYLON LOCKING FLANGE NUT M8	尼龙锁紧法兰螺母	6
F19-13	6.000.046	AUTO FUEL COCK ASSY.	自动燃油开关总成	1
F19-14	7.020.021	FUEL TUBE COMP. #1	燃油管总成1	1
F19-15	7.020.023	VACUUM TUBE COMP.	真空管总成	1
F19-16	7.020.022	VACUUM TUBE COMP. #2	真空管总成2	1
F19-17	6.000.056	FILTER	过滤器	1
F19-18	6.000.354	SAFETY BELT COMP.	保险带总成	1
F19-19	9.220.008	NUT M8	座椅螺母	2
F19-20	13-0401-00L	SEAT COMP	副驾驶椅	1
F19-21	13-0401-00R	SEAT COMP.L	驾驶椅	1
F19-22	9.700.001	SPECIAL BOLT, M7/16"X28	保险带螺栓	1
F19-23	9.700.002	WASHER BELT Φ12	保险带垫圈	9
F19-24	9.700.003	BELT NUT M7/16"	保险带螺母	9
F19-25	6.000.379	SEAT RALL SET.	座椅导轨	1
F19-26	9.090.005	TAIL LIGHT BULB. 21W/5W 12V	尾灯灯泡	1
F19-27	6.000.144	TAIL LIGHT	尾灯	1
F19-28	9.210.006	LOCKING NYLON NUT, M6	锁紧尼龙螺母	2
F19-29	9.900.840	BOLT SHARP M8X1.25X40	座椅螺栓	4

FIG. 20 REAR SWING ARM ASS'Y. UPPER




F20-1	9.220.012	LOCKING FLANGE NUT. M12	锁紧法兰螺母	1	
F20-2	8.010.042	WASHER. ENGINE MOUNT LINK	发动机安装支架垫圈	1	
F20-3	7.020.001	CUSHION. ENGINE MOUNT LINK	发动机安装支架垫片	1	
F20-4	8.020.045	SPACER. ENGINE MOUNT LINK	发动机安装支架衬碗	1	
F20-5	8.010.041	COLLAR. ENGINE MOUNT LINK	发动机安装支架衬管	1	
F20-6	9.300.012	WASHER. FLAT Φ12 8.010.042	发动机安装支架垫圈	1	
F20-7	9.200.012	NUT M12	螺母	1	
F20-8	6.000.026	ENGINE MOUNT BOLT PLATE	发动机安装支架螺栓	1	
F20-9	9.220.010	LOCKING FLANGE NUT. M10	锁紧法兰螺母	1	
F20-10	9.106.022	BOLT-WASHER M6X22	螺栓	3	
F20-11	9.210.008	LOCKING NYLON NUT. M6	锁紧尼龙螺母	3	
F20-12	9.110.045	BOLT-WASHER M10X1.25X45	螺栓	1	
F20-13	8.010.076	COLLAR. ENGINE MOUNT BOLT PLATE	发动机安装支架衬管	1	
F20-14	9.600.630	SCREW. PAN M6X30	大平头螺栓	2	
F20-15	7.010.084	COVER. ELECTRIC ASS'Y.	电器盒盖总成	1	
F20-16	2.000.062	REAR SWING ARM ASS'Y. UPPER	发动机吊架	1	
F20-17	9.112.060	BOLT-WASHER M12X1.25X60	螺栓	2	
F20-18	9.220.012	LOCKING FLANGE NUT. M12	锁紧法兰螺母	2	
F20-19	8.030.001	SWING ARM DOG BONE	后摇架连接杆	2	
F20-20	7.010.008	BUSH. CON' ROD	连接杆衬套	8	
F20-21	8.020.013	SPACER. CON' ROD	连接杆隔圈	4	
F20-22	9.108.016	BOLT-WASHER M8X1.25X16	螺栓	4	
F20-23	9.710.195	BOLT-WASHER M10X1.25X195	螺栓	1	
F20-24	8.010.025	COLLAR. ENGINE MOUNT	发动机安装衬管	1	
F20-25	7.020.024	COVER. REVERSE LEVER	倒档手柄罩	2	
F20-26	9.210.008	LOCKING NYLON NUT. M8	锁紧尼龙螺母	6	
F20-27	9.108.020	BOLT-WASHER M8X1.25X20	螺栓	2	
F20-28	8.040.004	SPRING. CABLE	钢索弹簧	2	
F20-29	6.000.064	BRACKET. LEVER	手柄支架	2	
F20-30	9.100.830	BOLT M8X30	螺栓	1	
F20-31	6.000.065	LEVER. REVERSE, PARKING BRAKE	倒档及驻车手柄	2	
F20-32	8.040.003	SPRING. LEVER	手柄弹簧	2	
F20-33	8.020.082	SPACER. LEVER	手柄隔圈	4	
F20-34	9.108.040	BOLT-WASHER M8X1.25X40	螺栓	2	
F20-35	9.300.005	WASHER FLAT Φ5	平垫圈	2	
F20-36	9.600.512	SCREW. PAN M5X12	大平头螺栓	2	
F20-37	9.220.008	LOCKING FLANGE NUT. M8	锁紧法兰螺母	4	
F20-38	7.020.026	COVER. LEVER. GREEN / BLACK	绿色/黑色手柄罩	2	
F20-39	6.000.051	ROD ADJUSTING. CABLE	钢索调节器	2	
F20-40	6.000.042	PARKING BRAKE/REVERSE LEVER ASS	驻车/倒档手柄总成	2	
	6.000.042-1	PARKING BRAKE/REVERSE LEVER ASS	驻车/倒档手柄总成	2	

FIG. 21 ENGINE/NUFFLER/AIR CLEANER




F21-1	6.000.157	REVERSE ASSY.	倒档总成	1	
F21-2	8.010.122	INTERNAL COLLAR REVERSE	倒档内衬圈	1	
F21-3	9.220.016	LOCKING FLANGE NUT M16	锁紧法兰螺母	1	
F21-4	9.106.012	FLANGE BOLT M6X12	法兰螺栓 GB5787	2	
F21-5	8.020.173	REVERSE BRACKET	倒档支架	1	
F21-6	9.220.008	LOCKING FLANGE NUT M8	开槽螺母	3	
F21-7	9.908.040	BOLT STRAP, M8X1.25X40	螺栓	1	
F21-8	8.020.056	AIR CLEANER CLAMP	空滤器夹箍	1	
F21-9	4.000.018	AIR CLEANER ASSY.	空滤器总成	1	
F21-10	6.000.024	CARBURETOR	化油器	1	
F21-11	2.000.009	ENGINE, 150CC	150发动机	1	
F21-12	8.030.037	MUFFLER RACK SUPPORT	排气管支架	1	
F21-13	9.100.612	BOLT, M5X16	螺栓	3	
F21-14	9.400.006	LOCKING WASHER Φ6	锁紧垫圈	3	
F21-15	6.000.074	MUFFLER COMP. EX	排气管总成	1	
F21-16	8.020.055	BOOT CLAMP	管夹	1	
F21-17	6.000.162	SIDE CASE BOOT	侧箱管	1	
F21-18	9.040.027	MUFFLER JOINT NUT, M6	排气管螺母(U型)	2	
F21-19	9.040.005	EX. PIPE GASKET	排气管垫片	1	
F21-20	7.010.047	AIR CLEANER CASE COMP	空滤器罩	1	
F21-21	9.805.003	TAPPING SCREW, M5X16	空滤器自攻螺钉	4	
F21-22	6.000.151	AIR CLEANER ELEMENT	空滤器滤芯	1	
F21-23	7.010.048	AIR CLEANER COVER	空滤器盖	1	
F21-24	7.010.033	CHAIN PROTECTOR, RR.	链条保护罩(半圆罩)	1	
F21-25	8.040.013	AIR CLEANER CLIP	空滤器管夹	1	
F21-26	7.010.057	AIR CLEANER DUCT	空滤器导管	1	
F21-27	8.020.176	AIR CLEANER CLAMP	空滤器夹	1	
F21-28	9.108.040	FLANGE BOLT, M8X1.25X40	法兰螺栓	1	

FIG. 22 REAR SWING ARM




F22-1	9.110.040	FLANGE BOLT M10X1.25X40	法兰螺栓	4	
F22-2	9.220.010	LOCKING FLANGE NUT M10	锁紧法兰螺母	4	
F22-3	6.000.006	CUSHION ASSY. RR	后避震	2	
F22-4	9.908.100	BOLT STRAP M8X1.25X100	螺栓	1	
F22-5	13-0601-00L	REAR FENDER BRACKET, L	后泥板支架左	1	
F22-6	9.210.006	LOCKING NYLON NUT M6	锁紧尼龙螺母	12	
F22-7	9.108.045	FLANGE BOLT M8X1.25X45	法兰螺栓	2	
F22-8	003-060016-01	FLANGE BOLT M6X16	法兰螺栓	12	
F22-9	7.010.031	DISC. RR COVER	刹车盘保护罩	1	
F22-10	9.908.012	BOLT STRAP M8X1.25X12	螺栓	1	
F22-11	13-0601-00R	REAR FENDER BRACKET, R	后泥板支架右	1	
F22-12	7.010.006	SWING ARM BUSHING	后机架衬套	4	
F22-13	8.010.028	SWING ARM COLLAR	后机架衬管	2	
F22-14	7.020.022	RR. BRAKE PAD SET	后刹车片	1	
F22-15	6.000.229	CALIPER ASSY. RR	后制动泵	1	
F22-16	7.010.032	CHAIN DISC GUARD	链条保护罩	1	
F22-17	7.010.028	BATTERY COVER	电瓶盖	1	
F22-18	7.020.023	BATTERY BAND	电瓶带	1	
F22-19	7.020.020	BATTERY LOWER CUSHION	电瓶垫	1	
F22-20	6.000.085	BATTERY (YTX12-BS)	电瓶	1	
F22-21	2.000.042	RR. LOWER SWING ARM COMP.	后摇架总成	1	
F22-22	9.220.012	LOCKING FLANGE NUT M12	锁紧法兰螺母	2	
F22-23	7.020.008	SWING ARM CUSHION BUSHING	后机架缓冲衬套	2	
F22-24	9.112.060	FLANGE BOLT M12X1.25X60	法兰螺栓	2	
F22-25	13-0204-00R	RR. FENDER, RH.	后泥板右	1	
F22-26	13-0204-00L	RR. FENDER, LH.	后泥板左	1	
F22-27	003-060016-00	BOLT, M6X16	后泥板螺栓	4	
F22-28	004-0600-00	NUT, M6	后泥板螺母	4	

FIG. 23 REAR HOUSING




F23-1	9.108.022	BOLT-WASHER M8X1.25X22	螺栓	4	
F23-2	8.010.053	DISC. RR. BRAKE	后刹车盘	1	
F23-3	9.220.008	LOCK FLANGE NUT. M8	锁紧法兰螺母	14	
F23-4	8.010.057B	REAR AXLE	后轮轴	1	
F23-5	9.070.002	CHAIN O-RING DRIVE.	O形圈链条56节	1	
F23-6	8.010.077	REAR SPROCKET	后链轮39牙	1	
F23-7	9.108.027	BOLT-WASHER M8X1.25X27	螺栓	4	
F23-8	9.040.006	DUST SEAL 50X34-7	防尘罩	2	
F23-9	8.030.008	COMP. HOUSING RR. AXLE BRG	后轮轴轴承壳总成	2	
F23-10	9.030.006	BEARING 6206	轴承	2	
F23-11	8.020.028	BEARING BASE	轴承座	2	
F23-12	9.108.040	BOLT-WASHER M8X1.25X40	螺栓	6	
F23-13	9.040.007	DUST SEAL 42X30-7	防尘罩	2	
F23-14	9.710.031	BOLT. TIRE M10X1.25X31	轮胎螺栓	8	
F23-15	8.010.089B	HUB. REAR AXLE	后轮轮毂	2	
F23-16	001-201010-00	TIRE. RR 21X10-10	后轮胎(无轮辋)	2	
F23-17	002-100100-03	RIM. RR 10" BLACK	后轮辋(10"黑色)	2	
F23-18	8.010.118	LUG NUT. CAP M10	盖形螺母	8	
F23-19	13-0902-03R	REAR. WHEEL ASSY. R	后轮总成右	1	
F23-20	9.700.016	SPACER. RR. WHEEL 16	后轮隔圈	2	
F23-21	9.800.016	CASTLE NUT. M16	六角螺母	2	
F23-22	9.500.430	COTTER PIN. 4X30	开口销	2	
F23-23	7.020.039	COVER. RR. HUB	后轮毂护套	2	
F23-24	13-0902-03L	REAR TIRE & WHEEL	后轮总成左	1	
F23-25	6.000.149	MASTER LINK. CHAIN	链条接头	1	
F23-26	9.108.045	FLANGE BOLT M8X1.25X45	法兰螺栓	3	
F23-27	9.040.008	DUST SEAL 42X28-7	油封	1	

FIG. 24 WIRE HARNESS/ELECTRICAL



F24-1	13-0205-03	SWITCH PANEL COVER	仪表板罩	1	
F24-2	13-0302-00	IGNITION START SWITCH	点火开关	1	
F24-3	6.000.159	ENGINE STOP BUTTON	发动机熄火开关	1	
F24-4	13-0301-00	KEY & HEADLIGHT SWITCH	钥匙及大灯开关	1	
F24-5	6.000.380	WIRE HARNESS.	总线	1	
F24-6	6.000.381	SOCKET COMP	(副线)电瓶线	1	
F24-7	9.100.620	BOLT M6X20	螺栓	2	
F24-8	9.210.006	NYLON LOCKING NUT M6	尼龙锁紧螺母	2	
F24-9	6.000.124	REGULATE RECTIFIER COMP.	整流器	1	
F24-10	6.000.035	STARTING RELAY	启动继电器	1	
F24-11	6.000.267	C.D.I. UNIT COMP.	CDI	1	
F24-12	9.210.005	NYLON LOCKING NUT M5	尼龙锁紧螺母	1	
F24-13	9.600.525	ROUND HEAD BOLT M5X25	圆头螺栓	1	
F24-14	6.000.025	IGNITION COIL COMP.	点火线圈	1	
F24-15	12.026.017	SPEEDOMETER	速度计	1	
F24-16	12.026.023	SPEEDOMETER SENSOR	速度计感应器	1	
F24-17	12.026.024	SCREW, M3X10 (GB818)	螺钉	1	
F24-18	12.026.025	SPRING WASHER, 3 (GB93)	弹簧垫圈	1	
F24-19	12.026.026	FLAT WASHER,3 (GB97.1)	平垫圈	1	
F24-20	12.026.027	NUT, M3 (GB6170)	螺母	1	
F24-21	9.100.005	BOLT, M6X20 (GB5787)	螺栓	1	
F24-22	9.200.006	NUT, M6 (GB6187)	螺母	1	

FIG. 25 REVERSE ASSY.



F25-1	9.100.625	BOLT M6X25	螺栓	6	
F25-2	8.010.122	INTERNAL COLLAR	内衬圈	1	
F25-3	8.020.167	KEEPER	保持器	2	
F25-4	8.010.123	DRIVE SPROCKET	驱动链轮	1	
F25-5	9.030.007	NEEDLE BEARING 26X35X20	滚针轴承	1	
F25-6	8.010.119	BEARING FLANGE PLATE	轴承法兰盘	1	
F25-7	8.010.169	GEAR CASE. L	齿轮箱左	1	
F25-8	8.010.170	GEAR CASE FLANGE PLATE	齿轮箱法兰盘	1	
F25-9	8.010.124	DRIVE GEAR	驱动齿轮	1	
F25-10	6.000.222	COUNTER GEAR SHAFT COMP	齿轮轴	1	
F25-11	8.010.125	GEAR SHIFT YOKE	拨叉	1	
F25-12	8.040.012	GEAR SHIFTING YOKE SPRING	拨叉弹簧	1	
F25-13	9.700.112	CIRCLIP Φ12	弹簧挡圈	1	
F25-14	8.010.121	DRIVE GEAR BUSHING	驱动齿轮衬套(白)	1	
F25-15	9.030.008	NEEDLE BEARING 22X30X14	滚针轴承	1	
F25-16	8.010.126	BUSHING. DRIVE GEAR	驱动齿轮衬套(黑)	1	
F25-17	8.030.029	GEAR SEAT	齿轮座	1	
F25-18	9.030.003	BEARING 6003 DDU	轴承6203	1	
F25-19	7.020.055	RUBBER OIL SEAL	橡胶油封	1	
F25-20	8.030.028	GEAR CASE. R	齿轮箱右	1	
F25-21	8.010.127	SHIFTING YOKE COVER	拨叉罩(拉线帽)	1	
F25-22	9.030.008	WASHER Φ8	垫圈	3	
F25-23	9.100.821	SCREW PAN M8X21	大平头螺栓	3	